Link 2 Home

QUICK GUIDE

Smart Battery Doorbell Weather Proof IP54




Thank you for purchasing your Link2Home smart home product. Get started using your new devices by downloading Link2Home Pro App, one convenient app that manages everything straight from your phone or tablet. Easily connect to your home Wi-Fi and control multiple devices from the touch of your fingertips.

Contents

Description	1-3
Install	4 - 5
Connect	6-8
Add a device manually	9-14
Add Device by EZ mode	15-19
Add a device by AP Mode	20-22
Settings	23
Frequently Asked Questions	24 - 25
Functions	26-28

What's in the Box

Please consult this checklist for all parts.




- L2H-BellBattery
- Double-sided tape
 Scr
 - Screws(3 kinds)

Instructions

- Battery (internal)
- House name / number plate
- Charging Plug

Warning

- 1. Do not install the device close to a heat source such as: an air conditioner unit, air vent or boiler exhaust system as this could cause interference.
- 2. Do not install the device behind obstacles such as windows as this may cause interference.
- 3. Try to avoid installing your device in direct sunlight, or with other lights directed at the device as this may cause interference.



Description

Power Port	AC 12~24V
Doorbell button	Press the button to activate the doorbell
Status light	Solid red light: the camera network is abnormal
	• Blinking red light: awaiting WiFi connection, or under
	connection (faster blinking)
	Solid blue light: camera running correctly
Microphone	Captures sound for your video and sound alerts
Micro SD card slot	Supports local Micro SD Card storage (Max.128G)
Reset	Press and hold the reset butten 5 seconds with pin to restore to factory defaults.
Charging	 Solid red light: battery is charging
Indicator	Solid blue light: finished charging
Switch	ON/OFF

Get Ready

- · Know your Wi-Fi network and password
- Locate a suitable mounting location
 Make sure your mobile device is running iOS® 9 or higher or Android[™] 5.0 or higher
- Make sure you're connecting to a 2.4GHz Wi-Fi network (Link2Home can't connect to 5GHz networks)

Install


Mode 1 Battery Installation



1. Mark the screw position using the doorbell bracket



2.Position the raw plugs



3.Fix the mounting bracket with screws or tape



4 Insert the doorbell into the bracket




5 Insert the doorhell into the bracket and tighten with the screw

Mode 2 AC Installation




1. Mark the screw position using the doorbell bracket





2.Position the raw plugs 3.Tighten the wire with a screwdriver



4.Fix the mounting bracket with screws or tape



5.Install the doorbell into the bracket



6.Insert the doorbell into the bracket and tighten with the screw

Connect

Download

Link2Home Pro is available for both iOS and Android OS. Search the name 'Link2Home Pro'in the App Store or Android Market, or scan the OR code below to download the App.

Support







Set up router

This device supports 2.4GHz frequency's only. It does not support 5GHz. Most household routers are dual band and so you should not need to change your routers settings. If however you do not have a dual band router please select an appropriate 2.4GHz network before WiFi configuration. When you set up your device ensure your mobile device, router and Link2Home device are as close as possible. You can move the device after set up.












Registration process

Step 1 Open the Link2Home Pro App, click "Register", read the "Privacy Policy" and click "Agree".





Step 2 Input a valid email address and click continue. Then enter the verification code from your email back into the App. (check you junk folder).

Register by Email		Verification Code
United Kingdom		
Email		
		Verification code has been sent to: admin@gmail.com Resend (56s)
☑ I Agree <u>User Agreement</u> and <u>Privacy Police</u>	x	

Add a device manually


Getting started

- Please follow the instructions and make sure the passwords are input correctly.
- One device can only be added with one App account, if the device has been added with another account already, then it can't be added to any other account again. Devices can be shared with other users in the Home Management settings.
- 3.If the device has been added to another account it will need to be removed first. After the device has been removed it will reset automatically and the status light will change from solid blue to flashing red.

8

Process

Step 1 Open the Link2Home Pro App, click "+" (in the upper right hand corner of the screen) or "Add Device". Then select "Add Manually".



Step 2 Select video surveillance from the left hand menu then choose Smart Doorbell (WiFi). Note your options may differ slightly from those shown above.



Step 3 Power the device on and make sure the indicator is flashing quickly or a prompt tone is heard. If you do not hear a prompt or see a flashing red light press and hold the reset button for 5 seconds (P3).





Step 4 Your device WiFi network will be the default network displayed.

Simply add your WiFi password or choose another network.


Click confirm and then continue and scan the QR code with your device.





Step 5 When you hear a beep . Click "I Heard a Prompt". The set up should take around 30 seconds.

Add Device by EZ mode



Step 6 The device is added, and the device nickname can also be changed in this interface.

If you cannot set up using the QR code method then try set up by EZ mode.



Step 1 In the Link2Home app, in the top corner of the Devices screen, click (+) or choose "Add Device".



Step 2 Select video surveillance from the left hand menu then choose Smart Doorbell (WiFi). Note your options may differ slightly from those shown above.

Step 3 In the top right-hand corner of your screen click on the word QR code and choose EZ mode.



Step 4 Ensure your device is in pairing mode (P.3) and then click next.

Step 5 Confirm your WiFi Settings.



Step 6 Your device will now scan your network for hunting devices.
This can take up to 2 mins.



Step 7 When complete you can complete set up from step 6 on P14.

Add a device by AP Mode

If you cannot set up using the QR code/EZ mode method then try set up by AP mode.



Step 1 In the Link2Home app, in the top corner of the Devices screen, click (+) or choose "Add Device".



Step 2 Select video surveillance from the left hand menu then then choose Smart Doorbell (WiFi). Note your options may differ slightly from those shown above.

Step 3 In the top right-hand corner of your screen click on the word QR code and choose AP mode.



Step 4 Ensure your device is in pairing mode (P.3) and then click next.



Step 5 Confirm your WiFi Settings.

Settings

Step 6 Follow the onscreen instructions and go to your list of WiFi networks on your device by clicking "Go to Connect" and choose the device named "SmartLife-XXXXX".



Step 7 Once connected the Link2Home app will reopen you can complete set up from step 6 on P14.



Device Information: Press to rename your device to something like "Garage" or "Driveway".

Tap-To-Run and Automation: Shortcut to your Smart events.

- Basic Function Settings:
- Flip Screen Rotate image 180°
 Watermark Turn on and off
- Talk Mode

IR Night Vision: Set On/Off or Auto

Sounds: Adjust the device volume
Detection Alarm Settings:

Human Body Filtering: Use this option to reduce the amount of false alerts. With this option enabled you will receive motion alerts when a person is detected.

PIR Set: Use this to turn your PIR on and off and adjust the intensity from Low (10) to High (50). Decrease the sensitivity to reduce your amount of alerts

Power Management Settings: See remaining battery life and set an alert for low battery warning. **Bell Settings:** Appears when you have paired a Bell Chime and

can be used to ajust volume and change tone.

Storage settings: Activates when an SD card is inserted. Go here to see your storage information and also format. your card here.

Purchase VAS: Purchase cloud storage.

Offline Notification: Periove an alert if y

Offline Notification: Recieve an alert if your device goes offline.

Device Sharing: Let friends or family keep an eye on what your
cameras see and get notifications.

Add to Home screen: Create a device shortcut from

Add to Home screen: Create a device shortcut from your phone screen.

Remove Device: Delete the camera from your account. Until it's deleted, it will always be linked to your account.

Frequently Asked Questions

1. Can I share with family and friends?

Yes, you can share your cameras with family and friends who will have access to view the camera and control your bulbs, plugs, and other Link2Home devices. In the Link2Home app, press the Profile button and click on the "Device Sharing" button, and you will be able to give or revoke sharing permissions. In order to share, the other user should already have downloaded the Link2Home app and registered a new account.

2.Recording and Micro SD Card Usage:

Without a Micro SD card (optional, sold separately), the smart Wi-Fi camera can show live camera video, save screenshots or videos of the camera stream to your phone for later, and record still snapshots of motion alerts when notifications are tumed on.

Installing a Micro SD card will further enable video recording and playback from your phone. When the card is installed, the camera will continuously record or event record and play back video to your phone until the card is full (up to 128GB supported).

3. Why is my device still on screen after resetting?

The reset button only resets the network configuration of the device and cannot change the configuration in the app. To remove the device refer to page 23.

4. How Many Cameras Can I Control?

Link2Home's app can control an unlimited amount of devices in an unlimited amount of locations. Your router may have a limit of how many devices can be connected to one router.

5.My Link2Home device has a strange name. How do I rename it?

From your main device list, click on one of the devices you want to rename, press the pencil button on the top right for advanced settings, and click Modify Device Name. You'll then be able to choose a more familiar name.

6. The device appears offline or unreachable, what should I do?

Make sure your Wi-Fi router is online and in range.

Make sure you have the latest Link2Home functionality by clicking "Check for firmware update" in your device settings.


7. What's the Wireless Range?

The range of your home Wi-Fi is heavily dependent on your home router and the conditions of the room. Check with your router specifications for exact range data.


24

Live view





Playback



your SD card in real time to

your device gallery to then

export

Link2Home.co.uk



Imported by Link2Home UK, West Sussex, RH194PQ EverFlourish Europe GmbH,Robert-Koch-Str. 4 D-66299 Friedrichsthal www.everflourish-europe.de

save to your device

gallery

Can't connect? Need help?



DO NOT RETURN

Link2Home support: link2home.co.uk/support